

FAIRING MOUNTING INSTRUCTIONS

Place the clamps on the fork with the **M6x35** screws. Tighten the screws to the point where the clamps can be moved, in order to adjust their final position once the rest of the pieces have been fixed.

Fasten the vertical securing plates of the Fairing on the end bore of the clamps, using the **M6x16** screws, in the position shown in image 1.

Fix the two angled plates, the smallest ones at the upper end of the vertical plates, to which the Fairing will also be anchored at its upper part. The **M6x16** screws will be used. Image 1 and 2.

Anchor the bottom part of the Fairing to the angled plates, the largest ones, which in turn will be anchored to the vertical plates, in the position that can be seen in the image 1. The **M6x16** screws will be used.

