

KAWASAKI VULCAN 500 EN

Highway bar mounting instructions

- First attach the highway bar on the anchor screw on the front part of the engine's bike. The screw is the one indicated in **(Image 1)**.

Remove the nut located on the opposite side and remove the screw.

Put in position the highway bar, to anchor it on the left side of the motorcycle, on the thread that has the highway bar plate on its end. **(Image 2)**. Thread the screw loosely.

On the right side the highway bar is fixed to the screw indicated in **(Image 3)**.

Replace the original screw with the **M8x70** screw included in the kit.

By the inside part of the frame, the plate of the highway bar is anchored at the end of this screw, which coincides in that position. The original nut is used to fix it.

- Once the highway bar has been placed in the previous anchors, position it to be able to place the forks that fix the frame by its lower part. The forks embrace the frame tubes, oriented from the outside to the inside. The anchoring position of this part is the one that can be seen in **(Image 4)**, on the right side and in the **(Image 5)** on the left side.

Place the two loose plates included in the kit by the inside part, on the anchor plane of the vertical tubes of the highway bar, between the nuts of the forks and the flattened plane of the tubes, to avoid that this flat part is bent when tightening the nuts.

- Once the highway bar is attached to all its anchorages, tighten the screws thoroughly.

