



HONDA VT750 Shadow C2 ACE, S, RS, VT400

ASSEMBLY INSTRUCTIONS

Top anchorage - The L plate welded to the top of the engine guard bow, on the right side will be placed in front of the frame tubes, between the tubes and the radiator.

The left side bow plate will pass behind the frame tubes, sandwiching with the right side, tightening between the two tubes, using the two M8x50 hexagon screws that are attached in the SPAAN kit, With the two flat washers and the two self-locking M8 nuts.

Bottom anchorage - At the bottom, is attached to the frame, embracing the tube with the two forks of M6. The plates will be positioned through the inside of the tube.

IMPORTANT: Position the engine guard as high as possible to prevent it from touching the ground when tilting the motorcycle.



Use and care: Keep accessories clean. Use only soap and water for cleaning. **DO NOT** use chemicals or abrasives or high pressure cleaners. Always keep them out of particularly corrosive environments.