



HYOSUNG AQUILA 125/250

ENGINE GUARD MOUNTING

Remove the two screws that secure the radiator. Instead, install the **M6x35** Allen screws from the **SPAAN** kit, with **6** wide wing flat washers. Behind the radiator put the **20x6x8** bushings and then the anchor plate of the **SPAAN** engine protector. Leave the assembly assembled but not tight. **(Figure A)**.

The underside of the engine guard should be directed towards the rear. These plates are anchored in the inner part of the horizontal tube, welded to the frame, in which, externally, the brackets of the foot plates are fixed.

Remove the original screw. Insert the **M8x120** screw on the right side (**M8x110** on the left), fixing the bracket on the outside and the bracket on the inside of the bracket, locking the bracket with the locking nuts of **M8** of the **SPAAN** kit. **(Figure B)**

Once all the pieces have been placed, tighten the screws.



(Figure A)



(Figure B)