

SISSYBAR / LUGGAGE RACKS MOUNTING INSTRUCTIONS YAMAHA VIRAGO XV 125/250 (until year 2005)

(1) Sideplates

In this model, the turn signals are anchored to the sides of the rear fender.

- The side plates of the SPAAN backrest are placed, at the rear, between the fender and the turn signals, loosening the nuts that they carry inside the fender until achieving a separation that allows the placement of the plates.

- On the front they are fixed on the screw that holds the fender. The original screw must be removed and placed in the hole where its head is housed, the 20x10x10.5 bushing and fixed with the M10 / 125x50 screws included in the SPAAN kit.

- Once the side plates are in place, fix the bow and the grill with the M6x20 screws and the M6 cap nuts included in the SPAAN kit.

YAMAHA VIRAGO XV 250 (from year 2009)

(1) Sideplates

This model has a chromed tube bow on the back and the turn signals are anchored on the sides of the fender.

To mount the SPAAN backrest, remove the original chrome arch.

- The side plates of the SPAAN backrest are fixed, at the rear, between the fender and the turn signals, loosening the nuts that they carry inside the mudguard until achieving a separation that allows the placement of the plates.

- On the front they are fixed on the screw that holds the fwnswe. The original bushing must be removed, the 20x10x10.5 bushing of the SPAAN kit must be replaced and fixed with the original screw or those of M10 / 125x50 included in the SPAAN kit.

- Once the side plates are in place, fix the bow and the grill with the M6x20 screws and the M6 cap nuts included in the SPAAN kit.

- Fix the seat with the M8x20 screw that is also included in the SPAAN kit.

(2) Sissybar uprights – luggage rack arch

Fix the sissybar upright (high or low), or in case of a luggage rack or luggage rack TC, the luggage rack arch to the sideplates SPAAN with the four screws M6x20. Put M6 nuts from the inside.



(3) Rack

*For installation in luggage racks kits or in any sissybars of our brand SPAAN. We must place it the inside of the small arch or the sissybar uprights and fix the assembly with the 4 screws M6x20 and nuts M6 included in the original kit. **In all LUGGAGE RACKS is required to mount the luggage rack arch**, to give more rigidity to the assembly.*



(4) Pad

*Join the set with four screws **M5x10** that accompany the kit. (In the back of the pad is marked with four holes in the fabric the position of the threads).*

