

SPAAN

MADE IN
SPAIN

KAWASAKI VN 900 CL/CUSTOM

SISSYBAR / LUGGAGE RACKS MOUNTING INSTRUCTIONS

(1) Sideplates

The sideplates of the sissy bar SPAAN are placed on the chrome trims that are on either sides of the rear fender.

On the front - Remove the screws that secure the chrome trim. The **14 mm** thick spacer caps included in the SPAAN kit is placed on the original spacer cap, put the side deck support SPAAN on this, and fix it with the **M8x40** screws included in the kit.

At the rear - Put the **9 mm** thick spacer cap of the SPAAN kit on the original spacer cap. Put the side deck support SPAAN on this and fix the assembly with screws **M8x35** included in the kit..



(2) Sissybar uprights – luggage rack arch

Fix the sissybar upright (high or low), or in case of a luggage rack or luggage rack TC, the luggage rack arch to the sideplates SPAAN with the four screws **M6x20**. Put **M6** nuts from the inside.

(3) Rack

For installation in luggage racks kits or in any sissybars of our brand SPAAN. We must place it the inside of the small arch or the sissybar uprights and fix the assembly with the 4 screws **M6x20** and nuts **M6** included in the original kit. **In all LUGGAGE RACKS is required to mount the luggage rack arch**, to give more rigidity to the assembly.



(4) Pad

Join the set with four screws **M5x10** that accompany the kit. (In the back of the pad is marked with four holes in the fabric the position of the threads).

