

SPAAN

KAWASAKI VULCAN 1600 CLASSIC TOURER VULCAN 1600 NOMAD

Assembly instructions luggage carrier

The SPAAN luggage carrier is fixed on the screws that hold the arch of the original backrest.
Remove the original screws and replace them with the **M8x55** screws included in the SPAAN kit.
The original nuts are used.

