

# SPAAN

MADE IN  
SPAIN

## SUZUKI M1800R

### SISSYBAR / LUGGAGE RACKS MOUNTING INSTRUCTIONS

#### (1) Sideplates

The sideplates of the sissy bar **SPAAN** are placed on the chrome trims that are on either sides of the rear fender.

**On the front** - Remove the screws that secure the chrome trim. The **20x13x8.5** spacer caps included in the **SPAAN** kit is placed **on the original trim**, put the side deck support **SPAAN** on this, and fix it with the **M8x80** screws included in the kit.

**At the rear** - Put the **20x15/13.5x8.5** spacer cap of the **SPAAN** kit **on the original trim**. (narrowest part of the cap should be directed forward). Put the side deck support **SPAAN** on this and fix the assembly with screws **M8x60** included in the kit.



#### (2) Sissybar uprights – luggage rack arch

Fix the sissybar upright (high or low), or in case of a luggage rack or luggage rack TC, the luggage rack arch to the sideplates **SPAAN** with the four screws **M6x20**. Put **M6** nuts from the inside.

#### (3) Rack

For installation in luggage racks kits or in any sissybars of our brand **SPAAN**. We must place it the inside of the small arch or the sissybar uprights and fix the assembly with the 4 screws **M6x20** and nuts **M6** included in the original kit. **In all LUGGAGE RACKS is required to mount the luggage rack arch**, to give more rigidity to the assembly.



#### (4) Pad

Join the set with four screws **M5x10** that accompany the kit. (In the back of the pad is marked with four holes in the fabric the position of the threads).

