

SPAAN

TRIUMPH AMERICA TRIUMPH SPEEDMASTER ENGINE GUARD INSTALLATION

At its upper part, the SPAAN engine guard is fixed to the lower screw of the two that attach the cradle to the frame.

Remove the original Allen screw, insert two washers of **18x6x10** in the hole in the head of the screw, and fix the assembly with the Allen screw of **M10 / 125x50** included in the kit. The anchorage on both sides is the same. (Figure A. View from the left side of the moto)

At the bottom, the welded strip in the engine guard is supported on the cross tubes of the motorcycle chassis. Place the platten included in the kit behind the tubes and tighten the tubes together with the **M8x45** screws, nuts and washers, also included in the kit. (Figure B. View from the right side of the moto)



(Figure A)



(Figure B)