



YAMAHA MIDNIGHT STAR 1300

MOUNTING SUPPORT OF HEADLIGHTS

The SPAAN headlight support is fixed to the front of the base of the indicator bracket. It is fixed in the anchor of this support and in another thread that is located to five centimeters, towards the center of the base.

- To install it, remove the chrome trim that covers the central part of the indicator light bracket. It is necessary to remove two Allen screws of tallow drop head that has in its lower frontal part. (Marked with two arrows in the image).



Once these screws have been removed, pull the trim towards the front to release it from its central elastic anchor.

- Remove the screws that fix the indicator bracket.

- On the exterior anchor, place on the original bracket of the turn signals, a 18x7x8 bushing , on top of it, the headlight support SPAAN and fix it with a hexagonal screw of M8x25.

- On the interior anchor, place a 16x3x8 bushing between the SPAAN headlight support and the base. Fix the assembly with a hexagonal M8x20 screw.



- Fit the original trim and the headlights.

- **THE ASSEMBLY IS THE SAME ON BOTH SIDES.**