

## Royal Enfield Bullet 500/Classic 500/Thunderbird 500

### Highway Bar Mounting Instructions

- The highway bar must be placed at the bottom on the anchor provided in the frame, below the lower screw of the two that fix the engine to the frame. To secure it, it must be used the two **M8x25** screws of the kit with its washers and lock nuts. **(Picture A)**
- At the top, the highway bar embraces the frame between the two platens **(Picture B)**. It must be secured it with the screw **M8x70**, washers and lock nut.



**(Picture A)**



**(Picture B)**

