

MASH FIVE HUNDRED 400 Highway bar mounting instructions

Top: The highway bar is fastened to the two frame anchors which fix the engine support plate, using the **M8x100** screws included in the kit.

Bottom: is fixed on the frame tubes with the forks included in the kit, that surround the tubes by the inside side and are anchored in the lower plates of the highway bar, and they are fixed with the **M6** self-locking nuts included in the kit.

WARNING: Position plates and screws before final tightening of the assembly.

