

# SPAAN



## YAMAHA V-MAX 1700

### SISSYBAR / LUGGAGE RACKS MOUNTING INSTRUCTIONS

#### (1) Sideplates

To secure the side plates of the SPAAN sissy bar must remove the original side chrome trims. By removing them, two holes can be seen in the rear fender that give access to the chassis of the bike. Put in that place the Ø20x30 caps included in the SPAAN kit. Put the side plates of the sissybar on them and fix them with the M8x50 screws.

Fix the chrome trim in its front anchorage. At its back part, it is anchored to the central screw hole that the sissybar side plates bear. Use the original M5 screw and the M5 self-locking nut included in the SPAAN kit. Tighten moderately in order not to force the piece.



#### (2) Sissybar uprights – luggage rack arch

- Fix the sissybar upright (standard or low), or in case of a luggage rack, the luggage rack arch to the sideplates SPAAN with the four screws M6x20. Put M6 nuts from the inside.



**(3) Rack**

For installation in luggage racks kits or in any sissybars of our brand **SPAAN**. We must place it the inside of the small arch or the sissybar uprights and fix the assembly with the 4 screws **M6x20** and nuts **M6** included in the original kit. **In all LUGGAGE RACKS is required to mount the luggage rack arch**, to give more rigidity to the assembly.



Join the set with four screws **M5x10** that accompany the kit. (In the back of the pad is marked with four holes in the fabric the position of the threads).

