

SPAAN

MADE IN
SPAIN

MOTO GUZZI V7 II Stone, Special, Racer

Highway bar mounting instructions

- **Upper anchorage.** Remove the regulator. It is fixed with two screws. Remove the two screws that are placed on the sides of the regulator. Place the plate, included in the SPAAN kit, in the place indicated in *Image 1*, by matching its four holes with the anchors of the previous plate.

Put the two side screws to fix the SPAAN plate in its position (Do not tighten the screws). Place the regulator on the plate and fasten with two M6x40 screws. (Do not tighten the screws). Anchor the top of the highway bar with two M8x20 screws included in the SPAAN kit, in the welded nuts on the top part of the kit plate. (*Image 2*). Do not tighten the screws until the lower anchorages are adjusted.

- **Lower anchors.** Remove the plastic caps (by pulling them), that cover the screws on the bottom part of the frame (*Image 3*). They leave visible the two screws of the frame anchorage. The highway bar will be anchored in the lower screw. (*Image 4*). Remove this screw.

Once the highway bar is placed on its top part, without tightening the screws, it is fixed at its bottom part. The Ø18x6xØ10.5 bushings must be placed between the highway bar plate and the frame. It is fixed with the M10x45 Allen screws, flat washers and the original nuts. (*Image 5*)

- When all the screws are placed It must be proceeded to progressively tighten them. (Including those that secure the regulator and its plate)

