

MOTO GUZZI V7III / V9

Highway bar mounting instructions

- **Upper anchorage.** Remove the regulator. It is fixed with two screws. Remove the two screws placed on both sides of the regulator on its support plate. Place the plate included SPAAN kit, in the place shown in *image 1*, by matching its four holes with the anchors on the plate. Insert the two lower side screws to secure the SPAAN plate in its position (Do not tighten the screws). *Image 2*.

Place the regulator on the plate and fix it to its lower part with a **M6x40** screw. (Do not tighten the screw)

Anchor the top of the highway bar with the two **M8x20** screws of the SPAAN kit, in the welded nuts on the top of the SPAAN kit plate. (*Image 3*). Do not tighten the screws until the lower anchors are tightened.

Once the highway bar has been inserted, the regulator will be fixed to its top part, placing the **Ø20x13** bushing of the SPAAN kit on the regulator and the assembly will be fixed with the **M6x60** screw. (*Image 4*).

- **Lower anchorage.** The highway bar is anchored in the lower screw of the two that fix the frame on both sides. (*Image 5*). On the inside the screw has a nut. Look at the position of this one.

Place the **Ø18x6xØ10.5** bushings included in the SPAAN kit, between the highway bar plate and the frame. Fix the assembly with **M10x45** Allen screws, flat washers and original nuts.

- When all the screws are in place proceed to tighten them progressively. (Including those ones that fix the regulator and its plate)

