

TRIUMPH BONNEVILLE T120 Sissybar mounting Instructions

The sissybar must be assembled by removing the original handle **A** of the motorcycle (**image 1**). The handle must be fixed with two screws **B** on each side (**image 1**).

The **SPAAN** sissybar should be fixed in the same anchors of the handle (**Image 2**).

Join the set with four screws **M5x10** that accompany the kit. (In the back of the pad is marked with four holes in the fabric the position of the threads) (**Image 3**).

