

SPAAN

MADE IN
SPAIN

HONDA REBEL 500

Highway bar mounting instructions

- **Bottom part:** The SPAAN highway bar is anchored in its lower part to the screw that fixes the frame tube and the engine anchor plate, this is indicated by an arrow in **image 1**.
- **Top part:** The fork of the SPAAN kit is placed hugging the frame tube by its inside part and after passing through the holes of the upper plate of the highway bar, it is fixed with the nuts and their corresponding washers. Indicated with two arrows in **image 2**.

IMPORTANT. The two parts of the highway bar are different. On the top plate of each of them, by its inside part is marked with a letter **D** which corresponds to the right side of the motorcycle and with a **Y** that corresponds to the left side.

