

SPAIN



MITT 125 TWIN

KEEWAY V-CRUISER 125/V302C - KEEWAY RK V125C

BENDA FOX 125/FOX 300

Highway bar mounting instructions

At the top part, Remove the screws that secure the radiator cover (**image 1**). Match the holes in the plate with the holes in the radiator cover and fix the assembly with the **M6x40** screws and that are included in the kit. A **Ø20x14x8,5** bushing on each side must be placed between the highway bar plates and the radiator cover. Once the highway bar is placed on its top part, without tightening the screws, it is fixed at its bottom part.

Lower anchorage: Remove the screw indicated in **image 3** (it has a nut on the right side). Place the **M10x285** threaded rod. Anchor the lower part of the highway bar on both sides at its ends. A **Ø20x30x10,5** bushing on each side must be placed between the highway bar plates and the motorcycle frame. Use the M10 self-locking nuts to fix it and the washers. Do not tighten the nuts. **Image 4**. Tighten all the screws.

