



TRIUMPH SPEEDMASTER

Sissybar mounting Instructions

The SPAAN sissybar is assembled by removing the original handle of the motorcycle. The handle is fixed with two screws on each side.

The backrest must be fixed to the same handle anchors with the **M8x20** screws included in the kit.

Join the pad with four screws **M5x10** included in the kit. The position of the threads is marked at the back of the pad with four holes.

