



ROYAL SUPER METEOR 650

Saddlebags Klick Fix bracket installation instruction

The saddlebags Klick Fix bracket is placed on the trims that flank the rear fender.

To mount them, remove the original screws. Place the **18x9x8.5** bushings on the trim and place the Klick Fix bracket on it and fix it with the **M8x30** screws and washers included in the kit.

